


SMS FLATSCREEN FH T1150/1450/2000

# MANUAL

- GB – Instructions for Mounting
- DE – Montageinformation
- IT – Istruzioni per il montaggio
- ES – Instrucciones para el montaje
- FI – Asennusohjeet
- FR – Instructions de montage
- NL – Montagevoorschriften
- PL – Instrukcja montażu
- RUS – Инструкция по монтажу
- ARB – عربي - طريقة التركيب
- SE – Monteringsinstruktion
- GR – Πληροφορίες συναρμολόγησης



PL041020..PL041025



|   |               |  |      |
|---|---------------|--|------|
| H | Washer 6,4    |  | (4x) |
| I | Screw M6x30   |  | (4x) |
| J | Level Screw   |  | (4x) |
| K | Level-feet    |  | (4x) |
| L | Plastic Cover |  | (4x) |
| M | Plastic Plug  |  | (6x) |

