Lumens™

www.MyLumens.com

Tap Share™

Quick Start Guide

⚠ Important

✼ Please activate your warranty at <u>www.MyLumens.com/reg</u>

✼ To download the latest version of the quick start guide, multilingual user manual, software, or driver, etc., please visit Lumens™ <u>http://www.Mylumens.com/support.php</u>

✼ To ensure a successful installation, please be sure to follow each step.

Product   Manual

Installation

TapShare Box

HDMI

TapShare Pod

PC

5V1A

HDMI / Mini DP++

iOS


5V1A

Switch to Mobile

Trust This Computer?

✔ **Trust** | Don't Trust

Projection from a
# Guest TapShare Pod

Guest
TapShare Pod

Host
TapShare Pod

Pairing

• **Pairing for any new TapShare Pod or using ethernet connection**

Switch to PC

Pairing is done when the screen shows "Pairing OK"

Android

⚠ **Please enable USB debugging before using.**

1. Go to Setting→System→About Phone

G Google
Services & preferences

ⓘ **System**
Languages, time, backup, updates

ⓘ **About Phone**
Pixel 2 XL

❓ Support & tips
Help articles, phone & chat, getting started

2. Click Build Number for 7 times to enable
   Developer Option

Kernel version
4.4.88-gb86dd0bc9690 (Android clang version
5.0.300080 (based on LLVM 5.0.300080))
android-build@wpra8.hot.corp.google.com #1
Wed Nov 8 06:19:15 UTC 2017

Build number
OPM1.171019.011   **x7**

You are now a developer!

3. Go to Developer option→USB Debugging→ On

☁	Backup On		
		USB debugging	⬤
		Debug mode when USB is connected	
{ }	**Developer options**		
🖫	System update Updated to Android 8.1.0		

4. Plug to TapShare Pod transmitter and
   Allow USB debug

*Note: Please select MTP or File Transferring
 in the notifications when USB is connected.

5V1A

Switch to Mobile